

StaticSmart® Pastoral Series ESD Sheet Vinyl

GENERAL INFORMATION

All substrates to receive moisture sensitive floor covering require proper moisture testing.

- Use cementitious patching and leveling compounds that meet or exceed Julie Industries' maximum moisture level and pH requirements. Use of gypsum-based patching and/or leveling compounds which contain Portland or high alumina cement and meet or exceed the compressive strength of 3,000 psi are acceptable.
- It is recommended that resilient floor covering installation shall not begin until all other trades are completed.
- Material should always be visually inspected prior to installations. Any material installed with visual defects will not be considered a legitimate claim as it pertains to labor cost.
- Perform Bond testing to determine compatibility of adhesive to the substrate.

STORAGE AND HANDLING

Store all rolls standing upright; **DO NOT** lay rolls down for long periods of time.

- When more than one roll of a color is being installed, all material should be from the same batch and the rolls must be installed in consecutive order. If material from more than one batch is to be used, the job should be laid out so that different batch numbers are installed side by side.
- Flooring material and adhesive must be acclimated to the installation area for a minimum of 48 hours prior to installation.

SITE CONDITIONS

Areas to receive flooring should be adequately lighted during all phases of the installation process. Controlled environments are critical. Fully functional HVAC systems are the best way to ensure temperature and humidity control. **DO NOT INSTALL RESILIENT FLOORING PRODUCTS UNTIL THE WORK AREA CAN BE TEMPERATURE CONTROLLED.**

- The permanent HVAC system must be operational and functional and set to a minimum of 65°F (20°C) or a maximum of 85°F, for a minimum of 2 days prior to, during, and permanently after installation. Once the installation is complete the temperature should not exceed 85°F.

SUBFLOOR INFORMATION

Note: All substrates to receive resilient flooring shall be dry, clean, smooth and structurally sound. They shall be free of dust, solvent, paint, wax, oil, grease, residual adhesive, adhesive removers, curing, sealing, hardening/parting compounds, alkaline salts, excessive carbonation/laitance, mold, mildew, and other foreign materials that might prevent the adhesive from bonding.

Installation

Wood Subfloors

Wood subfloors must be structurally sound and in compliance with local building codes.

- It is recommended that your chosen APA underlayment grade panels be designed for installation under resilient flooring, and carry a written warranty covering replacement of the entire flooring system.
- Double-Layered APA rated plywood subfloors should be a minimum 1" total thickness, with at least 18" well ventilated air space beneath.
- Insulate and protect crawl spaces with a vapor retarder covering the ground.
- Particleboard, chipboard, flakeboard, OSB, hardboard or similar are not recommended subfloor materials and require the additional layer of an APA 1/4" underlayment grade panel.
- **DO NOT** install over sleeper construction subfloors or wood subfloors applied directly over concrete.
- Double-Layered APA rated plywood subfloors should be a minimum 1" total thickness, with at least 18" well ventilated air space beneath.
- **DO NOT** install over sleeper construction subfloors or wood subfloors applied directly over concrete.

StaticSmart® Pastoral Series ESD Sheet Vinyl

Wood Subfloors (cont'd)

- Insulate and protect crawl spaces with a vapor retarder covering the ground.
- Particleboard, chipboard, flakeboard, OSB, hardboard or similar are not recommended subfloor materials and require the additional layer of an APA 1/4" underlayment grade panel.
- **DO NOT** install over sleeper construction subfloors or wood subfloors applied directly over concrete.
- Underlayment panels can only correct minor deficiencies in the sub-floor while providing a smooth, sound surface on which to adhere the resilient flooring.
- Any failures in the performance of the underlayment panel rest with the panel manufacturer and not with Julie Industries, Inc.
- StaticSmart resilient flooring is not recommended directly over fire-retardant treated plywood or preservative treated plywood. The materials used to treat the plywood may cause problems with adhesive bonding. An additional layer of APA rated 1/4" thick underlayment should be installed.
- Always follow the underlayment manufacturer's installation instructions.

STRIP – PLANK WOOD FLOORING:

- Due to expansion/contraction of individual boards during seasonal changes a 1/4" or thicker APA rated underlayment panels must be installed over these types of subfloors.
- Wood flooring installed directly over concrete is NOT an approved subfloor.

CONCRETE SUBFLOORS

NEW AND EXISTING CONCRETE SUBFLOORS SHOULD MEET THE GUIDELINES OF THE LATEST EDITION OF ACI 302 AND ASTM F 710, "STANDARD PRACTICE FOR PREPARING CONCRETE FLOORS TO RECEIVE RESILIENT FLOORING" AVAILABLE FROM THE AMERICAN SOCIETY FOR TESTING AND MATERIALS, 100 BARR HARBOR DRIVE, WEST CONSHOHOCKEN, PA 19428; 610-832-9585; [HTTP://WWW.ASTM.ORG](http://www.astm.org).

- All concrete substrates should be tested for IRH (Internal Relative Humidity) according to ASTM F 2170.
- Substrates shall be smooth, structurally sound, dry, clean and free of all foreign material such as dust, wax, solvents, paint, grease, oils, old adhesive residue, curing and hardening/ curing compounds, sealers and other foreign material that might prevent adhesive bond.
- On or below-grade slabs must have an effective vapor retarder directly under the slab.
- Wet curing 7 days is the preferred method for curing new concrete.
- Curing compounds (**DO NOT USE**). If present they can interfere with the bond of the adhesive to the concrete. Seek assistance from a substrate manufacturer if curing agents are detected.
- Remove curing compounds 28 days after placement, so concrete can begin drying.
- Concrete floors shall be flat and smooth within 1/8" in 6 feet or 3/16" in 10 feet.
- F-Number System: Overall values of FF 36/ FL 20 may be appropriate for resilient floor coverings.
- Expansion and isolation joints in concrete are designed to allow for the expansion and contraction of the concrete. Resilient flooring products should never be installed over expansion joints. Expansion joint covers designed for use with resilient floorings should be used. Control joints (saw cuts) may be patched and covered with resilient once the concrete is thoroughly cured, dry and acclimated.
- ASTM F 2170 IRH (Internal Relative Humidity) are required for the Julie Industries warranty. Three tests must be conducted for areas up to 1000 SF, and one additional test, for each additional 1000 SF. **RH may not exceed 85% RH**. Concrete floors must be tested per the latest edition of ASTM F 710.

NOTE: IT MAY NOT BE THE FLOOR COVERING INSTALLER'S RESPONSIBILITY TO CONDUCT THESE TESTS. IT IS, HOWEVER, THE FLOOR COVERING INSTALLER'S RESPONSIBILITY TO MAKE SURE THESE TESTS HAVE BEEN CONDUCTED, AND THAT THE RESULTS ARE ACCEPTABLE PRIOR TO INSTALLING THE FLOOR COVERING. WHEN MOISTURE TESTS ARE CONDUCTED, IT INDICATES THE CONDITIONS ONLY AT THE TIME OF THE TEST.

StaticSmart® Pastoral Series ESD Sheet Vinyl

LIGHTWEIGHT CONCRETE

All recommendations and guarantees as to the suitability and performance of lightweight concrete under resilient flooring are the responsibility of the lightweight concrete manufacturer. The installer of the lightweight product may be required to be authorized or certified by the manufacturer. Correct on-site mixing ratios and properly functioning pumping equipment are critical. To ensure proper mixture, slump testing is recommended.

- Lightweight aggregate concretes having dry densities greater than 90 lbs. per cubic foot may be acceptable under resilient flooring.
- Concrete slabs with heavy static and/or dynamic loads should be designed with higher strengths and densities to support such loads.
- Surface must be permanently dry, clean, smooth, free of all dust, and structurally sound.
- Perform Bond testing to determine compatibility of adhesive to the substrate.
- Three internal relative humidity tests should be conducted for areas up to 1000 SF. One additional test, for each additional 1,000 SF.

RADIANT HEAT

- Radiant heated substrates must not exceed 85°F (29°C) surface temperature.
- Seven days prior to installing resilient products over newly constructed radiant heated systems, make sure the radiant system has been on and operating at maximum temperature to reduce residual moisture within the concrete.
- 24 hrs. prior to installation lower the temperature to 70°F. and maintain that temperature for 48 hours after installation. After continuous operation of the radiant system, ensure the surface of the floor does not exceed 85°F (29°C).
- Use of an in-floor temperature sensor is recommended to avoid overheating.
- Hydronic systems only

RESILIENT FLOOR COVERING

WARNING! DO NOT SAND, DRY SWEEP, DRY SCRAPE, DRILL, SAW, BEADBLAST OR MECHANICALLY CHIP OR PULVERIZE EXISTING RESILIENT FLOORING, BACKING, LINING FELT, ASPHALTIC "CUTBACK" ADHESIVES OR OTHER ADHESIVES. These products may contain either asbestos fibers and/or crystalline silica. Avoid creating dust. Inhalation of such dust is a cancer and respiratory tract hazard. Smoking by individuals exposed to asbestos fibers greatly increases the risk of serious bodily harm. Unless positively certain that the product is a non-asbestos-containing material, you must presume it contains asbestos. Regulations may require that the material be tested to determine asbestos content and may govern the removal and disposal of material. See current edition of the Resilient Floor Covering Institute (RFCI) publication Recommended Work Practices for Removal of Resilient Floor Coverings for detailed information and instructions on removing all resilient covering structures. For current information go to www.rfci.com

- Must be single layered, non-cushion backed, fully adhered, and smooth.
- Must show no signs of moisture or alkalinity.
- Waxes, polishes, grease, grime, and oil must be removed.
- Cuts, cracks, gouges, dents and other irregularities in the existing floor covering must be repaired or replaced.
- Embossing leveler recommended to aid in proper bonding and to prevent telegraphing.
- Do not install over rubber based substrates.

NOTE: THE RESPONSIBILITY OF DETERMINING IF THE EXISTING FLOORING IS SUITABLE TO BE INSTALLED OVER TOP OF WITH RESILIENT, RESTS SOLELY WITH INSTALLER/FLOORING CONTRACTOR ON SITE. IF THERE IS ANY DOUBT AS TO SUITABILITY, THE EXISTING FLOORING SHOULD BE REMOVED, OR AN ACCEPTABLE UNDERLAYMENT INSTALLED OVER IT. INSTALLATIONS OVER EXISTING RESILIENT FLOORING MAY BE MORE SUSCEPTIBLE TO INDENTATION.

QUARRY TILE, TERRAZZO, CERAMIC TILE, POURED FLOORS (EPOXY, POLYMERIC, SEAMLESS):

- Must be totally cured and well bonded to the concrete.
- Must be free of any residual solvents and petroleum derivatives.
- Waxes, polishes, grease, grime, and oil must be removed.
- Show no signs of moisture or alkalinity.

StaticSmart® Pastoral Series ESD Sheet Vinyl

QUARRY TILE, TERRAZZO, CERAMIC TILE, POURED FLOORS (EPOXY, POLYMERIC, SEAMLESS):

- Cuts, cracks, gouges, dents, and other irregularities in the existing floor covering must be repaired or replaced.
- Fill any low spots, holes, chips and seams that may telegraph through the new flooring.
- Grind any highly polished or irregular/smooth surfaces.
- Quarry tile or Ceramic tile grout joints and textured surfaces must be filled with an embossing leveler or substrate manufacturer approved material.

OLD ADHESIVE RESIDUE

If the adhesive residue is asphalt-based (cut-back), or any other type of adhesive is present, it must be dealt with in one of two ways:

1. It may be mechanically removed such as: bead blasting or scarifying.
2. A self-leveling Portland based underlayment may be applied over cutback residue. Check with a substrate manufacturer for suitability, application instructions, and warranties.

Never use solvents or citrus adhesive removers to remove old adhesive residue. Solvent residue left in or on the sub-floor may affect the new adhesive and floor covering.

WARNING: SKIM COATING OVER OLD ADHESIVE IS NOT RECOMMENDED. THE ADHESIVE MAY BREAK DOWN AND COULD LEAD TO FAILURE. THE OLD ADHESIVE MAY NOT ALLOW THE RESILIENT FLOORING TO RETAIN ITS DIMENSIONAL STABILITY, POSSIBLY LEADING TO UNNECESSARY INDENTATIONS. SOME SOLVENT BASED 'CUT-BACK' ASPHALT-BASED ADHESIVES MAY CONTAIN ASBESTOS FIBERS THAT ARE NOT READILY IDENTIFIABLE. DO NOT USE POWER DEVICES, WHICH CAN CREATE ASBESTOS DUST IN REMOVING THESE ADHESIVES. THE INHALATION OF ASBESTOS DUST MAY CAUSE ASBESTOSIS OR OTHER SERIOUS BODILY HARM.

ADHESIVES

StaticSmart SDT+ conductive adhesive

Installer friendly, premium high strength conductive acrylic adhesive, designed to permanently install StaticSmart resilient flooring may be used on all grades of concrete: on, above, or below grade in the absence of excess moisture, as well as suspended approved wood floors.

Note: To properly apply SDT+ snap white chalk lines along areas where adhesive will be spread to ensure an even and straight line of adhesive. Spread adhesive with a 1/16" (wide) x 1/16" (depth) x 1/16" (apart) square notch trowel to cover the chalk line on one side and meet up to it on the other. If glue is spread over the chalk line it will need to be removed. (DO NOT overlap adhesive.) Troweling new adhesive over an area already spread may result in telegraphing. Be very careful not to leave any adhesive ridges or puddles.

Porous substrates: Resilient flooring may be placed into adhesive after 5–10 minutes open time. Install resilient flooring into adhesive when the spacing in between the adhesive transitions from wet to dry. Roll with a 100 lb. roller immediately after flooring is placed, ensuring complete contact with the adhesive. **DO NOT** exceed the working time of the adhesive: 45 minutes.

Non-porous substrates: Once the adhesive is troweled backroll the adhesive to prevent trowel ridges from telegraphing. Install resilient flooring into adhesive when it becomes dry to the touch, with little or no transfer to fingers. This will normally require 25 to 30 minutes of drying time at suggested installation temperature and humidity, **DO NOT** exceed working time of the adhesive: 45 minutes. Roll with a 100 lb. roller immediately after flooring is placed, ensuring material has complete contact with adhesive.

IMPORTANT: DO NOT use SDT+ as a pressure sensitive adhesive. Loss of adhesion can result if the flooring is not installed within the working time of the adhesive. **DO NOT** allow the adhesive to completely dry. Trowel ridges must still be pliable to receive flooring. Too much open time will result in an insufficient bond and may promote telegraphing of the trowel ridges.

Perform Bond testing to determine compatibility of adhesive to the substrate.

Note: Open time and working times may vary based on temperature, humidity, substrate porosity, trowel size and air flow.

- Heat welding can be performed 1 day after installation.
- Safety and Clean-up:** Wet adhesive should be cleaned with soap and water on a clean cloth. Sheet Dried adhesive may require the use of mineral spirits.

StaticSmart® Pastoral Series ESD Sheet Vinyl

INSTALLING RESILIENT SHEET VINYL PRODUCTS

- Ensure that moisture tests have been conducted and that the results do not exceed 85% In-Situ relative humidity when tested according to ASTM F 2170.
- PH of concrete sub-floor surface must be between 7&10.
- The permanent HVAC system turned on and set to a minimum of 65°F (20°C) or a maximum of 85°F, for a minimum of 7 days prior to, during and after installation. After the installation, the temperature should not exceed 85°F.
- Flooring material and adhesive must be acclimated to the installation area for a minimum of 48 hours prior to installation.
- Use only Julie Industries approved flooring adhesives.
- Use a 1/16" wide x 1/16" deep x 1/16" apart square or (U) notch trowel only
- Material should always be visually inspected prior to installations. Any material installed with visual defects will not be considered a legitimate claim as it pertains to labor cost.
- Pastoral Series ESD Sheet Vinyl is dimensionally stable. It will not shrink or compress. It is recommended to allow material 24 hours unrolled and lying flat on the job site prior to installation.
- Install all cuts and rolls in consecutive sequence.
- Ensure that all recommendations for sub-floor and jobsite conditions are met prior to installation. Once the installation has begun, you have accepted these conditions.

NOTE: Recommended to use floor protection after installation. DO NOT use a plastic adhesive based protection system.

CUTTING AND FITTING SHEETS:

- Measure, identify, and mark your control line for the sheet good installation.
- Cut the required length off the roll, including enough to run up the wall 2" at either end.
- Push the length of the sheet as close to the starting wall as possible, letting the extra length run up the wall at the far end. The material should still be aligned on the control line.
- Place a straight edge on top of the material along the starting wall, and proceed to cut along the straight edge. This cut technique is a direct scribe. Pattern scribing, three wall scribing, use of a wall trimmer or freehand cutting all are acceptable methods as well.
- Push the fitted sheet gently to the starting wall while keeping it aligned.
- Free hand knife the opposite wall of the starting wall. Pattern Scribing or direct scribe is also acceptable. Continue to free hand knife, pattern scribe, or direct scribe material for the remainder of the installation area.
- Opening up the sheets in the width/length is acceptable.
- **DO NOT** fold as care should be taken not to crease material.
- **DO NOT** back roll vinyl backed flooring.
- Snap white chalk lines or use pencil along areas where adhesive will be spread to ensure an even and straight line of adhesive. **DO NOT** use permanent marker.
- Carefully place flooring into adhesive, working toward the wall. **DO NOT FLOP MATERIAL IN** because air may be trapped, causing bubbles.
- After material has been laid into the adhesive, recess scribe the seams using either the scribe blade or scribe pin.
- Hold the knife blade straight up and down to make final cut. **DO NOT UNDERCUT**
- Repeat the same procedure for additional seams in the room.
- Recommended to massage curl the end joints to help ensure they lay flat. Putting weight on the end joints will help to ensure proper bonding as the adhesive sets up.

StaticSmart® Pastoral Series ESD Sheet Vinyl

CUTTING AND FITTING SHEETS (cont'd):

- Roll the glued areas right away to within 6" of the seam on either side with a 3 section 100 lb. roller. Roll the seam area with a hand-seam roller to bring the seam edges to equal heights. Re-roll the entire glued floor area with the 100 lb. roller within the working time of the adhesive. Continue to roll the floor throughout the working day to ensure a proper bond.

NOTE: TO ENSURE PROPER BONDING OF THE MATERIAL, IT IS RECOMMENDED TO ROLL IN THE MATERIAL NEXT TO THE WALLS WITH A HAND SEAM ROLLER.

- Heat welding Pastoral Series ESD sheet flooring is always required.
- Heat weld seams the following day.

Contact Julie Industries product support for assistance if not familiar with scribing techniques or heat welding.

SEAMING:

Seams may be cut by either the straight edging (edge trimming) one side and recess scribing the second sheet, or by the overlap and double cut method.

Recess scribe method (on non-patterned material)

- Trim approximately 1/2" off one selvage edge of seam with a straightedge and sharp knife or edge trimmer. Cut the second sheet allowing proper extra length. Position the second sheet with a 1/2" to 1" overlap over first sheet at the seam. Set recess scribes so that the seam will have a slight gap, about half the thickness of a razor blade. If cut too full, it will result in bubbles or ridges. Recess scribe seam. Repeat for as many sheets as necessary to complete the area.

Double cut method

- Utilizing a straight edge and a new razor blade hold the knife straight up and down and cut through both pieces in one cut. Cutting through the top layer while scoring half of the bottom layer at the same time, and finishing with a hook blade, is acceptable.

NOTE: SET RECESS SCRIBES SO THAT THE SEAM WILL HAVE A SLIGHT GAP, ABOUT HALF THE THICKNESS OF A RAZOR BLADE. IF CUT TOO FULL, IT WILL RESULT IN BUBBLES OR RIDGES. DO NOT SEAM FACTORY EDGES.

HEAT WELDING:

- Heat welding is the required procedure for seams, coving, and corner fill pieces.
- Professionally heat welded seams provide a strong, watertight, hygienic, monolithic surface.
- The welding rod (4 mm) is designed to melt at the same temperature as the sheet flooring, thermally fusing the two together.
- Heat welding should be done 24 hours after installation.
- Seam edges should be slightly gapped and vertical. Wide gapped or undercut seams will prevent quality welds. The depth of the groove should be 1/2 to 2/3 the thickness of the material using a 3.5 mm grooving tool. Be careful not to go too deep. The groove must also be centered along the two edges. This is very important to ensure proper strength and bonding of the welding rod.
- Clean grooves thoroughly of all foreign contamination, including dust.
- Use only professional quality welding equipment that will maintain sufficient temperatures. A narrow preheat 4mm tip is required.
- Preheat welding gun prior to welding. Temperature should be set approximately 750°F.
- Practice on a scrap piece to fine tune temperature and pace. Long extension cords may affect welding temperature settings.
- Determine the correct welding speed by ensuring that the welding rod actually fuses into the groove. On the scrap practice piece try to pull the weld out of the groove. If the rod pulls out of the groove adjust temperature until it will no longer pull out of the groove. Tip must remain parallel to the finished floor. A small ridge must form on either side of the welding rod, at the vinyl surface. If no ridge forms, you have not heat welded the seam correctly.
- While the welding rod is still warm, trim off 1/2 the excess rod with a spatula knife or Mozart skiver and trim plate in one continuous movement.

StaticSmart® Pastoral Series ESD Sheet Vinyl

HEAT WELDING (cont'd):

- After the rod has cooled to room temperature, make the final trim pass using a razor sharp spatula knife or Mozart skiver in one continuous movement.

FLASH COVE INSTALLATION:

- Flash coving is an extension of the sheet flooring up the wall to form a wall base.
- Seams in the flash coved areas should be treated the same as seams throughout the rest of the installation.
- 4" and 6" flash coving is most common. For all heights in excess of 6" check applicable local building codes.
- Use 4100 or S150 adhesive in flash coved areas. Use a brush or roller to apply adhesive to the wall and cove stick area.
- Adhesive must be allowed some open time, usually about 10 – 15 minutes.
- After fitting material into adhesive, use a hand roller to assure contact with the adhesive.

NOTE: We recommend using floor protection after installation. DO NOT use a plastic adhesive based protection system.

Julie Industries warrants its sheet, tile and welding rods to be free from manufacturing defects for ten years from the date of purchase. Julie does not warrant installers' workmanship. Workmanship errors should be addressed to the contractor who installed the floor. Your Julie Industries StaticSmart floor should be professionally installed by contractors who have demonstrated expertise in installing commercial floors. For complete warranty information, limitations and terms and conditions please call customer support: 1-978-276-0820